




















CCA-101 II 赤外LED使用時
オーディオリモコン設定

メーカー	スイッチ設定	リモコン型番	カーオーディオ
Carrozzeria		CD-R660 CXC8663 CXE1354	AVIC-HRZ099 AVIC-HRZ088,AVIC-HRZ008,AVIC-HRZ009
		CXC3904	AVIC-ZH900MD,AVIC-ZH990MD
		CXC3904 CXC6584 CXC6585	AVIC-VH099,AVIC-VH099MD,AVIC-VH099MDG AVIC-VH009,AVIC-VH009MD,AVIC-VH009MDG AVIC-ZH009,AVIC-ZH009G,AVIC-VH099 AVIC-ZH099G,AVIC-H099,AVIC-H009
		CXC7589	AVIC-HRZ88,AVIC-HRZ99 AVIC-HRZ99GII,AVIC-HRZ88GII AVIC-HRZ99G,AVIC-HRZ88G
		CXB5925 CXB8597	AVIC-XH09V
		CXB5799	AVIC-D9900,AVIC-D9900V,AVIC-D9100
		CXC4118	AVIC-DRZ90,AVIC-DRZ80 AVIC-DRV20,AVIC-DRV50 AVIC-DRV10
		CXC5892	AVIC-HRZ09,AVIC-HRZ08
		CXC9462	AVIC-VH9990
KENWOOD		KCA-RC527J	
ALPINE		RUE-4187 RUE-4208 RUE-4192 RUE-4202	X088/X09/X077/X075シリーズ
			X008シリーズ
ECLIPSE		E3008MC	
		RMC101	
ADDZEST clarion		RCB-158-500	
Panasonic		CA-RC55D YEFX992012	
		YEFX99240	CN-HDS930MD,CN-HDS935MD CN-HDS950MD,CN-HDS955MD CN-HDS900D,CN-HDS905D
		YEFX999580 YEFX9996095 YEFX9996531	CN-HX3000D,CN-HX900D,CNHW880D CN-HW850D,CN-HW1000D,CN-HX1000D CN-HW830D,CH-HDS910D,CN-HDS940TD CN-HDS960TD,CN-HDS700TD,CN-HDS710TD CN-HDS915TD,CN-HDS945TD,CN-HDS965TD CN-HDS635TD,CN-HDS625TD,CN-HDS625D CN-HW890D
Victor		RM-RK41J	